

Factory Reset your Polycom VVX phone

- 1. Turn off the device.
- 2. On the "Loading Application" screen press "Cancel."



- 3. As soon as the "Welcome" message appears, press and hold down "1," "3," "5."
- 4. Release them only when seeing the "Enter Password" message appear.



- 5. For password use the phone's MAC address (using CAPS for letter) and press "OK."
- 6. After the restart your phone will be successfully reset (with default password "4, 5, 6")
- 7. Reboot will take place then select PIN Authentication.

Input User's Extension.

Password: 60(Extension)